




How to attach the tape to a traditional gate handle

		
<p>Force a screwdriver through the two metal loops to open them.</p>	<p>Run the tape through the bottom of the loops and then back through the gap.</p>	<p>Pull the tail and remove the screwdriver when the desired tension is achieved. Don't forget to tidy up the loose end by folding back on itself and attaching a clip</p>

Electric current is able to go through the handle thus maintaining continuity.


Opening the gate will temporarily disconnect the portion of the fence beyond the gate.

The insulated handle allows you to open and close your paddock without risk of a shock to you.



StockGuard Handy Hints

Removing a tang from the buckle of the tensioner will provide more room to hook the gate handle.



If the tape is twisted, change the position of the key to match the looped ends.

